25 Tips and Techniques for Transwell[®] Permeable Supports from Corning

CORNING

Transwell Permeable Supports have been a lab standard for decades. Over that time, we've accumulated numerous tips and techniques for getting the most out of these versatile cell culture tools. Below are 25 of our favorites.

- 1. When changing the media for drug transport assays, always aspirate from the basolateral side first, then the apical side. When replacing the media, add in the opposite order (apical then basolateral).
- 2. Add liquid to 24-well inserts more easily by using every other tip on a multiple channel pipettor.
- 3. When seeding cells for migration assays, more is not always better. Optimization of the seeding concentration for each cell type is critical. For additional information on optimizing chemotaxis assays refer to Considerations when Optimizing your Chemotaxis or Invasion Assay with Corning Transwell Permeable Supports (CLS-AN-188).
- 4. When seeding cells on the underside of inserts, flip the entire plate upside down to allow the inserts to sit on the lid of the plate. Add cells as a single drop to the center of the insert and cover the majority of the membrane surface. After the cells have attached, replace the plate over the inserts and invert again. See Seeding Cells onto the Underside of Transwell Permeable Supports (CLS-AN-533).
- 5. The receiver plates that come with the 96 HTS Transwell insert product are untreated. Treated receiver plates are available in clear, white and black.
- 6. Polyester (PET) inserts offer the best cell visualization properties.
- 7. Cells requiring extracellular matrix coatings on plastic substrates will also require them on permeable supports. Several protocols are available. Contact Corning for more information.
- 8. The 96 HTS Transwell inserts have access ports adjacent to Column One to allow aspiration and media addition to feeder reservoirs without having to separate the insert plate from the reservoir.
- 9. More consistent TEER measurement can be achieved when running drug transport applications by allowing plates to equilibrate to room temperature before measuring.
- 10. Crystal violet is a very easy and effective fixative/stain for enumerating cell migration when using Transwell[®] inserts.



- 11. When performing drug transport assays, more consistent results can be achieved by optimizing the passage number of the cells being used. For in-house MDCK cell studies, for example, the Corning Applications group uses cells between passages 11 and 25.
- 12. Transwell 6.5 mm inserts are sold with 12 inserts per plate. The 12 remaining wells allow for further insert manipulation to be conducted during assays after cell culture is complete.
- 13. When using the swabbing and staining method for enumerating migration or invasion, swab non-migrated cells prior to fixation and staining.

- 14. To image cells on the polycarbonate surface, fix and stain cells with any of the following stains: Crystal violet, Papanicolaou, Hematoxylin, Giemsa, May-Grunwald, or Wright's.
- 15. To help optimize cell growth on inserts, do not allow cell cultures to exceed 85% to 90% confluence on the cultureware that is to be used for seeding on the inserts.
- 16. To avoid damaging the cell culture surface, take care not to allow pipette tips to come in contact with the fragile membrane when removing or adding cells or medium to the insert.
- 17. Use care when transporting inserts to the incubator after cell seeding. Avoid spilling medium from the insert into the receiver plate, which will carry suspended cells into the receiver plate.
- 18. To speed up cell attachment to the membrane, try pre-soaking the inserts in cell growth medium containing serum proteins prior to cell seeding.
- 19. It is critical to use the proper Falcon® receiver plate with FluoroBlok™ insert systems. The FluoroBlok inserts (individual format) should be used with Falcon Cell Culture Insert Companion plates (24-well, Cat. No. 353504) to ensure proper positioning of the inserts in the wells. The plates supplied with FluoroBlok HTS 24 and 96 Multiwell inserts must be used for running the assay, labeling and reading samples to achieve reliable results.
- 20. To avoid swabbing and counting non-migrating cells in migration/invasion assays, consider using a dissociation solution to collect migrated cells in the receiver plate followed by fluorescent staining and reading. To further simplify the protocol, use FluoroBlok light blocking membranes and detect migrated cells directly on the membrane with no swabbing or cell dissociation.

- 21. Always check the underside of inserts for bubbles after addition of chemoattractant (or stain for FluoroBlok inserts) as they can interfere with cell growth and counting.
- 22. When using FluoroBlok inserts, always verify your plate reader results visually (i.e., using an inverted fluorescent microscope).
- 23. HUVECs and other endothelial cells demonstrate a bell curve response to growth factors such as VEGF. If their concentration is too high or too low, they may yield similar responses.
- 24. The endothelial cell source (HUVEC vs. HMVEC, etc.) can affect levels of protein expression and subsequent response to chemoattractants.
- 25. The FluoroBlok membrane exhibits negligible autofluorescence across the visible spectrum (400 to 700 nm) as demonstrated by top-reading fluorescence data. However, there is a low level of fluorescence background in bottom reading mode due to autofluorescence of, and/or reflection from, the polystyrene well bottom of the base plate.

Use of excessively high gain settings or failure to run the appropriate controls can often give the false impression that the FluoroBlok membrane blocks light inefficiently or has high inherent autofluorescence.

Warranty/Disclaimer: Unless otherwise specified, all products are for research use or general laboratory use only.* Not intended for use in diagnostic or therapeutic procedures. Not for use in humans. These products are not intended to mitigate the presence of microorganisms on surfaces or in the environment, where such organisms can be deleterious to humans or the environment. Corning Life Sciences makes no claims regarding the performance of these products for clinical or diagnostic applications. *For a listing of US medical devices, regulatory classifications or specific information on claims, visit www.corning.com/resources.

Corning's products are not specifically designed and tested for diagnostic testing. Many Corning products, though not specific for diagnostic testing, can be used in the workflow and preparation of the test at the customers discretion. Customers may use these products to support their claims. We cannot make any claims or statements that our products are approved for diagnostic testing either directly or indirectly. The customer is responsible for any testing, validation, and/or regulatory submissions that may be required to support the safety and efficacy of their intended application.

CORNING

Corning Incorporated Life Sciences

www.corning.com/lifesciences

NORTH AMERICA t 800.492.1110 t 978.442.2200

> ASIA/PACIFIC Australia/New Zealand t 61 427286832 Chinese Mainland t 86 21 3338 4338

India t 91 124 4604000 Japan t 81 3-3586 1996 Korea t 82 2-796-9500 Singapore t 65 6572-9740 Taiwan t 886 2-2716-0338 EUROPE CSEurope@corning.com France t 0800 916 882 Germany t 0800 101 1153 The Netherlands t 020 655 79 28 United Kingdom t 0800 376 8660 **All Other European Countries** t +31 (0) 206 59 60 51

LATIN AMERICA grupoLA@corning.com Brazil t 55 (11) 3089-7400 Mexico t (52-81) 8158-8400