


These instructions are provided as a guideline for the trained craftsperson.



Content


1. Cage nuts installation.....2

2. Tool2


2. Housing installation3

3. 19 inch frame housing installation.....5


1. Cage nuts installation




2. Tools




2. Housing installation




NOTE: Slide pins into the designated mounting holes.








NOTE: Tighten the screws




3. 19 inch frame housing installation (brackets to be ordered separately)




Screw 19 inch brackets. Position in the frame can be adjusted


1U




2U




4U





General view



Corning Optical Communications GmbH & Co. KG • Leipziger Strasse 121 • 10117 Berlin, GERMANY
+00 800 2676 4641 • FAX: +49 30 5303 2335 • www.corning.com/opcomm/emea

Corning Optical Communications reserves the right to improve, enhance, and modify the features and specifications of Corning Optical Communications products without prior notification. A complete listing of the trademarks of Corning Optical Communications is available at www.corning.com/opcomm/trademarks. All other trademarks are the properties of their respective owners. Corning Optical Communications is ISO 9001 certified. © 2018 Corning Optical Communications.