

GENERAL PACKAGING RECOMMENDATIONS

To ensure the plates are transported in their optimum condition, it is recommended the guidelines indicated below are followed :

- Radiation shielding glass plates should be cleaned with Isopropranol agents only.
- Each plate should be wrapped in acid-free tissue paper. Failure to do so could result in surface attack during transportation, due to excess humidity or condensation.
- It is also recommended that each plate is then wrapped in kraft or brown paper for extra protection.
- Each wrapped plate should be separated by cardboard dividers in the crate.
- The empty spaces in each crate should be well packed with polystyrene to ensure there is no movement of plates during transportation.

In case of damages or quality problems after unpacking process, please contact our Customer Service Team, in charge of radiation shielding glass.

Details :

Corning SAS
7 bis avenue de Valvins
CS 70156 Samois sur Seine
77215 Avon Cedex - France
Tel: +33 (0) 1.64.69.74.00
Fax: +33 (0) 1.64.69.71.29